
KE Rectangular duct fan
KT Rectangular duct fan
RS Rectangular duct fan AC/EC
RSI Rectangular duct fan AC/EC



Table of content

1	Introduction	1	12.2.1	Product dimensions KE fans and KT fans	14
1.1	Product description	1	12.2.2	Product dimensions RS fans, RS EC fans	15
1.2	Intended use	1	12.2.3	Product dimensions RSI fans, RSI EC fans	17
1.3	Document description	1	12.3	Wiring diagrams	18
1.4	Product overview	1	12.3.1	Wiring diagrams for AC fans	18
1.5	Name plate	2	12.3.2	Wiring diagrams for EC fans	19
1.5.1	Type designation	2	12.3.3	Wiring diagrams for speed controller for AC motors	20
1.6	Product liability	2	12.3.4	Wiring diagrams for speed controllers for EC motors	24
2	Safety	3	12.3.5	Wiring diagrams for ON/OFF controls for EC motors	26
2.1	Safety definitions	3	12.3.6	Wiring diagrams for demand control for EC motors	26
2.2	Safety instructions	3	13	Accessory overview	30
2.3	Personal protective equipment	4	14	EU Declaration of Conformity	32
3	Transportation and storage	4	15	UK Declaration of Conformity	33
4	Installation	5			
4.1	To do before the installation of the product	5			
4.2	To Install the product	5			
4.2.1	To connect the ducts to the product	5			
5	Electrical connection	6			
5.1	To do before the electrical connection	6			
5.2	To connect the product to the power supply	6			
5.3	Speed controller for EC motors	6			
5.4	Motor protection for EC motors	6			
5.5	Speed controller for AC motors	6			
5.6	To install motor protection for AC motors	7			
6	Commissioning	7			
6.1	To do before the commissioning	7			
6.2	To do the commissioning	7			
7	Operation	8			
7.1	To start a product with an EC motor	8			
7.2	To start a product with an AC motor	8			
7.3	To stop the product	8			
7.3.1	To stop the product in an emergency	8			
8	Maintenance	8			
8.1	Maintenance schedule	8			
8.2	To clean the product	9			
8.3	Spare parts	9			
9	Troubleshooting	10			
10	Disposal	12			
10.1	To disassemble and discard the parts of the product	12			
11	Warranty	12			
12	Technical data	13			
12.1	Technical data overview	13			
12.2	Product dimensions	14			

1 Introduction

1.1 Product description

The product is a rectangular duct fan with a casing made from galvanized steel. The motor and the fan impeller are attached to the inspection lid for easy maintenance.

KE fans and KT fans are supplied with an AC motor. RS fans and RSI fans are available with an AC motor or an EC motor. RSI fans have 50 mm mineral wool for thermal and acoustic insulation.

The product is not supplied with a safety switch, external speed controller or flexible duct connections, these parts are available and recommended as accessories.

1.2 Intended use

The product is intended for transportation of clean or contaminated air with a maximum temperature of 60–70 °C. Refer

to www.systemair.com for the maximum temperature of transported air for the applicable motor type. The product is applicable for ambient temperatures of -25 °C to +70 °C.

The product is intended for installation in any angle in a rectangular duct system in indoor environments.


The product is not applicable for transportation of air that contains explosive, flammable or aggressive media. The product is not applicable for locations where there is a risk of explosion.

1.3 Document description

This document contains instructions for installation, operation and maintenance of the product. The procedures must be done by approved personnel only.


Speak to Systemair for more information on how to install the product in different installation locations.

1.4 Product overview



- | | |
|--|-----------------|
| 1. Connection box (KE, KT, RS 60–35 – RS 100-50 and RSI) | 5. Fan impeller |
| 2. Name plate | 6. Service lid |
| 3. Connection box (RS 30–15 – RS 50–25) | 7. Motor |
| 4. Airflow direction arrow | 8. Casing |

1.5 Name plate



1. Type designation: Product name, dimension and motor type. Refer to 1.5.1 Type designation.
2. Input power, W
3. Frequency, Hz
4. Certifications
5. Scannable code ¹
6. Find more information about the product on the Systemair documentation portal¹
7. Country of production
8. Airflow direction arrow
9. Weight, kg
10. Serial number: part number/production number/production date
11. IP class, enclosure class
12. Current, A
13. Voltage, V

Note:

The data on the name plate applies to “standard air” that is specified in the standard ISO5801.

1.5.1 Type designation

Product name	KE	KT	RS sileo	RS EC sileo	RSI sileo	RSI EC sileo	
Dimension	50–25–4**1	40–20–4	30–15	30–15	60–35 L1	60–35	
	50–30–6**1	50–25–4	40–20 L	40–20	60–35 L3	70–40	
	60–30–6**1	50–25–6	40–20 M	50–25	60–35	60–35 M1	80–50
			50–30–4**1	50–25	60–35	60–35 M3	100–50
			60–30–4	60–35 L1	70–40	70–40 L3	
			60–30–6	60–35 L3	80–50	80–50 L3	
			60–35–4	60–35 M1	100–50	80–50 M3	
			60–35–6	60–35 M3		100–50 L3	
			70–40–4	70–40 L3			
			70–40–6	80–50 L3			
			80–50–6	80–50 M3			
			100–50–6**1	100–50 L3			
	Motor type	230 V, 1–phase	230 V, 3–phase	230 V, 1–phase	EC: Electronically commutated, 1–phase, 230 V	230 V, 1–phase	EC: Electronically commutated, 1–phase, 230 V
400 V, 3–phase			230 V, 3–phase	EC: Electronically commutated, 3–phase, 400 V	230 V, 3–phase	EC: Electronically commutated, 3–phase, 400 V	
	400 V, 3–phase	400 V, 3–phase					

1. ** after the product name means that the product is only for sale outside the EU

1.6 Product liability

Systemair is not liable for damages that the product causes in these conditions:

- The product is incorrectly installed, operated or maintained.

1. Use a mobile device to scan the scannable code and go to the Systemair documentation portal for more documentation and document translations.

- The product is repaired with parts that are not original spare parts from Systemair.
- The product is used together with accessories that are not original accessories from Systemair.
- The product is used without motor protection.

2 Safety

2.1 Safety definitions

Warnings, cautions and notes are used to point out specially important parts of the manual.



Warning

If you do not obey these instructions, there is a risk of death or injury.



Caution

If you do not obey these instructions, there is a risk of damage to the product, other materials or the adjacent area.

Note:

Information that is necessary in a given situation.

2.2 Safety instructions



Warning

Read the warning instructions that follow before you do work on the product.

- Read this manual and make sure that you understand the instructions before you do work on the product.
- Obey local conditions and laws.
- The ventilation contractor and the operator are responsible for correct installation and intended use.
- Keep this manual at the location of the product.
- Do not install or operate the product if it is defective.
- Do not remove or disconnect safety devices.
- Make sure that you can read all warning signs and labels on the product when it is installed. Replace labels that have damage.
- Only permit approved personnel to work on the product and to be in the adjacent area during all work on the product.
- Make sure that you know how to stop the product quickly in an emergency.
- Use applicable safety devices and personal protective equipment during all work on the product.
- Before you do work on the product, stop the product and wait until the fan impeller stops. Make sure that there is no voltage on the motor terminals.
- If the maintenance is not correctly and regularly done, there is risk of injury and damage to the product.
- Only do the maintenance as given in this manual. Speak to Systemair technical support if other servicing is necessary.
- Always use spare parts from Systemair.
- Sound levels exceeding 70 dB(A) may occur depending on model and size. Visit www.systemair.com for more detailed information about your product.
- The product is not to be used by persons, including children, with reduced physical, sensory or mental

capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

- Do not allow children to play with the device.

2.3 Personal protective equipment

Use personal protective equipment during all work on the product.

- Approved eye protection
- Approved protective helmet
- Approved hearing protection
- Approved protective gloves
- Approved protective shoes
- Approved work clothing

3 Transportation and storage



Warning

Make sure that the product does not become damaged or wet during transportation. A damaged or wet product can cause fire or electric shock.

- Before you move the product to the installation location, examine the packaging for damages.
- Do not move the product by the cables, terminal box, fan impeller, protection grille, inlet cone or silencer.
- If lifting equipment is used, make sure that the lifting equipment can hold the weight of the product. Refer to the name plate for information. Do not lift the product by the packaging.



Warning

Do not walk below a lifted product.

- Keep the correct side of the packaging up during transportation. Refer to the arrows on the packaging.
- Load and unload the product carefully.
- Keep the product in a dry and clean location during storage. Make sure that the ambient temperature during storage is between -10 and $+30$ °C. A stable ambient temperature prevents damage from condensation.
- Keep the product in storage for maximum 1 year.

4 Installation

4.1 To do before the installation of the product

- Make sure that you have the necessary installation accessories:
 - Refer to [13 Accessory overview](#) for an overview of the accessories.
 - If you install the product outdoors, it is necessary to install a weather protection roof.
 - To decrease vibrations transmitted from the product to the duct system, Systemair recommends to install vibration dampers, fast clamps or flexible connections.
 - If you install the product with free suction or free discharge, it is necessary to install a protection grille. Make sure that the safety distance agrees with the standard DIN EN ISO 13857 and the standard DIN 24167-1.
- Use installation material with fire resistance rating for the installation location.
- Examine the packaging for transportation damage and remove the packaging from the product carefully.
- Examine the product and all components for damage.
- Make sure that the motor effect and the fan performance agrees with the expectations at the installation location.
- Make sure that the information on the name plate and the motor name plate agrees with the operation conditions.
- Install the product in a location where there is space for commissioning, troubleshooting and maintenance.
- Make sure that the installation location is clean and dry, for full safety during electrical work.
- Make sure that the installation surface has sufficient capacity to hold the weight of the product.
- Refer to the airflow direction arrows on the name plate or on the product to install the product in the correct position.
- Make sure that all cable glands are tight against the cables to prevent leaks.


4.2 To Install the product

Note:


The arrow on the name plate shows the direction of the airflow.

Note:

All fans can be installed in any angle.



- 1 Install the product in any angle, using applicable installation equipment. Obey these steps when applicable:
 - If the product is installed in the ceiling, use pendulum bars, wires or other applicable installation equipment. Pendulum bars, wires and nuts or other installation equipment are not supplied by Systemair.
 - If the product is installed on the floor, add insulation below the product to prevent unwanted noise and vibrations.
 - If the product is installed near a wall, keep a distance of minimum 400 mm from the product to the wall to prevent unwanted vibrations.
- 2 To open the service lid and access the motor or the connection box, remove the 2 screws on the top of the service lid.




4.2.1 To connect the ducts to the product


Note:

Systemair recommends to use flexible connections to attach the duct to the product. Flexible connections are available as accessories.


- 1 If applicable, put flexible connections on each side of the product and use guide rails to connect the product and the flexible connections. Guide rails are not supplied by Systemair.



- 2 Put the ducts on each side of the product and the attached flexible connections. Use guide rails to attach the flexible connections to the ducts.



- 3 If you install the product near a duct bend, do these steps to prevent vibrations, unwanted noise and decreased air pressure:
- Measure the distance (A) between the product and the duct bend.
 - Make sure that the distance (A) is a minimum of 2.5 x the diameter (B) of the duct system. For circular ducts, (B) is the nominal diameter. For rectangular ducts, (B) is the hydraulic diameter.



5 Electrical connection

5.1 To do before the electrical connection

- Make sure that the electrical connection agrees with the product specification on the motor name plate.
- Make sure that the environment for electrical connection is clean and dry.
- Make sure that the wiring diagram that is included with the supply of the product agrees with the terminals in the connection box.

5.2 To connect the product to the power supply

- Complete the electrical connection for the motor. Refer to the motor wiring diagram that is included with the product.
- Make sure that the cross section of the protective earthing is equal to or larger than the cross section of the phase conductor.
- Install a circuit breaker in the permanent electrical installation, with a contact opening of a minimum 3 mm at each pole.
- If a residual current device (RCD) is installed, make sure that it is an all-current sensitive RCD. Consider if the product has a frequency converter, uninterruptible power supply (UPS), or an EC motor. EC motors have a leakage current to earth that is ≤ 3.5 mA.

5.3 Speed controller for EC motors

- EC motors are controlled through a stepless 0–10 V signal.
- Do not use power supply for the speed controller.
- Refer to [12.3 Wiring diagrams](#) and the instruction manual for the external speed controller.

5.4 Motor protection for EC motors

EC motors have an integrated motor protection. Reset the motor protection by disconnecting the fan from power supply for 60 seconds.

5.5 Speed controller for AC motors

Note:

The speed controller alternatives are different for different motor types. Make sure that your motor is compatible with the speed controller type before you use it.

The speed can be controlled by voltage reduction using a transformer. It is also possible to control the fan speed with frequency converter if the installed frequency converter has built in all-pole sine filter and shielded cables are not needed.

5.6 To install motor protection for AC motors

- If the product has an built in motor protection, reset by disconnecting the product from power for 60 seconds.
- If the motor has temperature monitors such as thermal contacts (TK) or thermistors lead out into the terminal box, these must always be connected in the control circuit using appropriate motor protection.
- Make sure that an overheated motor cannot start again automatically when it becomes cool.
- Install the motor cables and the temperature monitor apart.
- If the motor does not have temperature monitors, install a motor protection switch.

6 Commissioning



Caution

- If strong vibrations occur during commissioning, immediately increase or decrease the fan speed until the vibrations are decreased. Continuous strong vibrations can cause damage to components.
- Do not increase the fan speed to a higher rpm value than the maximum value that is given on the name plate.

The commissioning report is found at www.systemair.com.

6.1 To do before the commissioning

- Make sure that the installation and electrical connection are correctly done.
- Visually examine the product and accessories for damage.
- Make sure that the safety devices are correctly installed.
- Make sure that there are no blockages in the air inlet and the air outlet.
- Make sure that installation material and unwanted objects are removed from the product and the ducts.

6.2 To do the commissioning

- 1 Set the installed safety switch in the OFF position.
- 2 If it is possible to get access to the fan impeller, do the steps that follows:
 - a. If it is necessary, remove parts of the installation.
 - b. Turn the fan impeller by hand and make sure that it turn easily.
 - c. Record the result in the commissioning report.
- 3 Make sure to turn the product in a direction that agrees with the related arrow on the product.
 - a. Record the result in the commissioning report.
- 4 If you removed parts of the installation to get access to the fan impeller, install the removed parts again.
- 5 Set the installed safety switch in the ON position.
- 6 Start the product.
- 7 Set the minimum operation speed.
- 8 Increase the operation speed gradually to the maximum operation speed.
 - a. Examine the vibrations in the casing and the bearing areas at all speed levels.
 - b. Make sure that the vibrations agree with the specifications in DIN ISO 14694.
 - c. Make sure that none of the speed levels cause unwanted noise in the product.
 - d. Record the result in the commissioning report.
- 9 Record the necessary data in the commissioning report.

7 Operation



Caution

EC motors must be set to ON/OFF via the control input. To stop the product via mains supply decreases the life time of the motor. Systemair recommends to install external speed controller for easy access to control the input signal.

7.1 To start a product with an EC motor

- 1 Make sure that the 0–10 V signal is set to “0” with the speed controller.
- 2 Set the installed safety switch in the ON position and wait 5 seconds.
- 3 Adjust the fan speed with the 0–10 V signal speed controller. If an external speed controller is not installed, adjust the fan speed directly with the integrated potentiometer.

7.2 To start a product with an AC motor

- 1 Set the installed safety switch in the ON position.
- 2 Install the external speed controller. Refer to the instruction manual for the installed speed controller.

7.3 To stop the product

- 1 Set the installed speed controller in the OFF position. Refer to the instruction manual for the installed speed controller.
- 2 Set the installed safety switch in the OFF position.

7.3.1 To stop the product in an emergency

- Set the installed safety switch in the OFF position.

8 Maintenance



Warning

Set the installed safety switch in the OFF position before you do the maintenance unless the instructions tell you differently. Make sure that the safety switch is not accidentally set in the ON position.


8.1 Maintenance schedule

The intervals are calculated from continuous operation of the product.

Maintenance task	Usual operation conditions		Unusual operation conditions. ¹		
	Each 6 months	Each year	Each 3 months	Each 6 months	Each year
Visually examine the product and its components for damage, corrosion and dirt.		X		X	
Examine the fan impeller for damage and imbalance.		X		X	
Clean the product and the ventilation system.	X		X		
Do a check of all fasteners and make sure that they are fully tightened.		X			X
Make sure that the product and its components are correctly operated.	X			X	
Measure the power consumption and compare the result with the information on the name plate.		X		X	
If vibration dampers are installed, make sure that they operate correctly and examine them for damage and corrosion.		X			X
Make sure that the electrical protective equipment and the mechanical protective equipment operates correctly.		X			X
Make sure that you can read the name plates of the product.		X		X	
Examine all cable connections for damage. Make sure that the cable glands are tight against the cables.		X			X
If flexible connections are installed, examine them for damage.	X			X	

1. The unusual operation conditions are classified as follows: If a stable ambient temperature is higher than 30 °C or lower than -10° C, if the temperature changes are large or if very contaminated air is transported.

8.2 To clean the product



Caution

- Do not clean the product with a high-pressure washer.
- Do not clean the product with steel brushes or sharp objects.
- Do not bend the fan impeller blades.
- Be careful not to move the balance weights on the fan impeller.

- Remove dirt from the fan and the duct.
- If access to the fan impeller is possible, clean the fan impeller with a moist cloth or soft brush.

8.3 Spare parts

- When you send an order for spare parts, include the serial number of the product. The serial number is found on the name plate.
- For more information about spare parts, contact technical support.
- Always use spare parts from Systemair.
- To find spare parts, refer to the scannable code on the name plate.

9 Troubleshooting

Note:


If you cannot find a solution to your problem in this section, speak to Systemair technical support.

Problem	Cause	Solution
The product does not operate smoothly.	The fan impeller is not correctly balanced.	Speak to Systemair technical support.
	There is dirt on the fan impeller.	Clean the fan impeller carefully. Refer to 8.2 To clean the product .
	The fan impeller has damages or deformations because the transported air contains aggressive media.	Speak to Systemair technical support.
	The fan impeller does not turn in the correct direction.	Make sure that the electrical connection is correctly done.
	The fan impeller has deformations because of too high temperatures.	<ul style="list-style-type: none"> • Replace the fan impeller. • Make sure that the temperature of the transported air is not higher than the value on the name plate.
	There are unusually strong vibrations in the product or the duct system.	Make sure that the product is correctly installed. Do a check of the duct system.
	The product is operated in a resonant frequency range.	Increase or decrease the fan speed until the product operates smoothly. Refer to 6 Commissioning .
The air output is not sufficient.	The fan impeller does not turn in the correct direction.	Make sure that the electrical connection is correctly done.
	The electrical connection is not correctly done.	Make sure that the electrical connection agrees with the wiring diagrams.
	The air pressure is too low because of incorrect installation.	Do the necessary changes in the duct system and installed components to increase the air pressure. Refer to 6 Commissioning .
	The airflow shutters are closed or not fully open.	Adjust the airflow shutters.
	There is blockage in the air inlet or the duct system.	Remove the blockage.
	The product is not applicable for the installation location.	Make sure that the product is applicable for the installation location.
	The motor power is decreased because of too high temperature in the motor.	<ul style="list-style-type: none"> • Do a check of the ambient temperature. • Make sure that the space around the motor is sufficient to keep the temperature down.
There is unusual noise when the product starts or operates.	There is strain in the connections of the duct system.	Loosen the connections, align the parts of the duct system correctly and tighten the connections.

Problem	Cause	Solution
Thermal contacts, PTC or resistors are released.	The fan impeller does not turn in the correct direction.	Make sure that the electrical connection is correctly done.
	A phase loss occurred.	If the motor is a 3-phase motor, make sure that no phase is missing. Note: This is not applicable for EC motors.
	The motor is overheated.	<ul style="list-style-type: none"> Do a check of the motor cooling impeller. If it is possible, measure the resistance to do a check of the motor winding.
	The capacitor is not connected or not correctly connected. Note: This is not applicable for EC motors or 3-phase AC motors.	Connect the capacitor correctly. Refer to the included motor wiring diagram.
	There is blockage in the motor.	Speak to Systemair technical support.
The fan speed does not get the nominal value.	Defective motor winding.	If it is possible, measure the resistance to do a check of the motor winding.
	The speed control is not correctly set.	Set the speed control correctly.
	The fan impeller cannot turn freely because of mechanical blockage.	Remove the blockage.
	Phase loss occurs.	If the motor is a 3-phase motor, make sure that no phase is missing.
The motor does not rotate.	A component in the power supply is defective.	Do a check of the power supply. Replace defective components and connect the power supply again.
	The electrical connection is not correctly done.	Make sure that the electrical connection agrees with the wiring diagrams.
	The motor protection is released because the motor is overheated.	Let the motor become cool. Reset the motor protection. Find the cause of the overheated motor.
	A phase loss occurred.	If the motor is a 3-phase motor, make sure that no phase is missing.
The electronic components or the motor is overheated.	The motor is overloaded or the ambient temperature is too high.	Let the motor become cool. Reset the motor protection. Find the cause of the overheated motor.
	The motor is overloaded.	Make sure that the product is applicable for the installation location.
	The ambient temperature is too high.	Make sure that the product is applicable for the installation location.
	The cooling of the product is not sufficient.	Make sure that the space around the motor is sufficient to keep the temperature down.

10 Disposal

The product follows the WEEE directive. This symbol on the product or the packaging of the product shows that this product is not domestic waste. The product must be recycled at an approved disposal location for electrical and electronic equipment.



10.1 To disassemble and discard the parts of the product

- 1 Disconnect and disassemble the product in the opposite sequence of electrical connection and installation.
- 2 Recycle the product parts and the packaging at an applicable disposal location.
- 3 Obey the local and national requirements for disposal.

11 Warranty

For warranty claims, send a written maintenance plan and the commissioning report to Systemair. The warranty is only applicable for these conditions:

- The product is correctly installed and operated.
- Motor protection is used.
- The instructions in the data sheets are obeyed.
- Maintenance instructions are obeyed.
- A product that is not operated continuously is operated for a minimum of 1 hour each month.

12 Technical data

12.1 Technical data overview

Max. temperature of transported air, °C	Refer to the data sheet in the online catalogue at www.systemair.com .
Max. ambient temperature, °C	
Sound pressure, dB	
IP class	
Voltage, current, frequency, enclosure class, weight	Refer to the name plate. Refer to 1.5 Name plate for more information.
Motor data	Refer to the motor name plate or the technical documentation from the motor manufacturer.

12.2 Product dimensions


Note:

If the unit of measure is not specified, the dimensions are given in millimetres.

Note:

The arrow in the dimension drawing shows the direction of the airflow.


12.2.1 Product dimensions KE fans and KT fans



	A	B	C	D	E	F	G	ØH	I	J	K
KE 50-24-4** 1	290	270	248	540	520	498	34	10	532	8	610
KE 50-30-6**1	340	320	298	540	520	498	34	10	562	8	695
KE 60-30-6**1	340	320	298	640	620	598	47	10	642	8	715
KT 40-20-4	240	220	198	440	420	398	32	10	502	8	530
KT 50-25-4/6	290	270	248	540	520	498	68	10	532	8	610
KT 50-30-4**1	340	320	298	540	520	498	68	10	562	8	695
KT 60-30-4/6	340	320	298	640	620	598	89	10	642	8	715
KT 60-35-4/6	390	370	348	640	620	598	92	10	717	8	805
KT 70-40-4/6	440	420	398	740	720	698	92	10	787	8	900
KT 80-50-6	540	520	497	840	820	798	113	10	880	8	1090
KT 100-50-6**1	540	520	497	1040	1020	998	113	10	980	8	1140

1. ** after the product name means that the product is only for sale outside the EU.

12.2.2 Product dimensions RS fans, RS EC fans



The dimensions are split over 2 separate tables. See Table 2 for measures I-O

Table 1

	A	B	C	D	E	F	ØG	H
RS 30–15 sileo	79	230	120	402	254	8	10	254
RS 40–20 M sileo	99	310	125	502	352	8	10	352
RS 40–20 L sileo	99	310.5	125	502	352.5	8	10	352.5
RS 50–25 sileo	125	366	85.5	532	423	8	10	423
RS 60–35 M1 sileo	128	490	145	717	524	8	10	524
RS 60–35 M3 sileo	109	491	147	717	521	8	10	530
RS 60–35 L1 sileo	109	491	147	717	521	8	10	530
RS 60–35 L3 sileo	128	490	145	717	524	8	10	524
RS 70–40 L1 sileo	189	491	215	787	524	8	10	518
RS 70–40 L3 sileo	189.5	490	215	787	524	8	10	524
RS 80–50 M3 sileo	182.5	644	190	882	614	8	10	650
RS 80–50 L3 sileo	182.5	614	190	882	644	8	10	644
RS 100–50 L3 sileo	298.5	614	290	982	644	8	10	644
RS 30–15 EC sileo	79	230	120	402	254	8	10	257
RS 40–20 EC sileo	98	310	125	502	354	8	10	359


Table 1 (continued)

	A	B	C	D	E	F	ØG	H
RS 50–25 EC sileo	125	366	87	532	417	8	10	427
RS 60–35 EC sileo	109	491	147	717	521	8	10	530
RS 70–40 EC sileo	189	491	215	787	524	8	10	518
RS 80–50 EC sileo	182.5	614	191	882	644	8	10	638
RS 100–50 EC sileo	287	634	260	982	684	8	10	678

Table 2

	I	J	K	c-c L	M	c-c N	O
RS 30–15 sileo	217	190	148	170	298	320	340
RS 40–20 M sileo	267	240	198	220	398	420	440
RS 40–20 L sileo	267	240	198	220	398	420	440
RS 50–25 sileo	317	290	248	270	498	520	540
RS 60–35 M1 sileo	402	390	348	370	598	620	640
RS 60–35 M3 sileo	431	390	348	370	598	620	640
RS 60–35 L1 sileo	431	390	348	370	598	620	640
RS 60–35 L3 sileo	402	390	348	370	598	620	640
RS 70–40 L1 sileo	465	440	398	420	698	720	740
RS 70–40 L3 sileo	452	440	398	420	698	720	740
RS 80–50 M3 sileo	560	541	498	520	798	820	840
RS 80–50 L3 sileo	573	541	498	520	798	820	840
RS 100–50 L3 sileo	583	541	498	520	998	1020	1040
RS 30–15 EC sileo	227	190	149	170	298	320	340
RS 40–20 EC sileo	293	240	198	220	398	420	440
RS 50–25 EC sileo	326	290	248	270	498	520	540
RS 60–35 EC sileo	431	390	348	370	598	620	640
RS 70–40 EC sileo	465	440	398	420	698	720	740
RS 80–50 EC sileo	580	541	498	520	798	820	840
RS 100–50 EC sileo	580	540	498	520	998	1020	1040

12.2.3 Product dimensions RSI fans, RSI EC fans



The dimensions are split over 2 separate tables. See Table 4 for measures J-P

Table 3

	ØA	B	C	D	E	F	G	H	c/c I
RSI 60–35 M1 sileo	10	492	391	92.5	99.5	139.5	532	347.5	370
RSI 60–35 M3 sileo	10	508	391	108	100	140	532	348	370
RSI 60–35 L1 sileo	10	508	391	108	100	140	532	348	370
RSI 60–35 L3 sileo	10	492	391	92.5	99.5	139.5	532	347.5	370
RSI 70–40 L1–L3 sileo	10	564	441	114	170	202	532	397	420
RSI 80–50 M3 sileo	10	683	541	133	144	195	656	497	520
RSI 80–50 L3 sileo	10	662	541	112.5	144.5	194	656	497	520
RSI 100–50 L3 sileo	10	683	541	133	215	302	678	498	520
RSI 60–35 EC sileo	10	508	391	108	100	140	532	348	370
RSI 70–40 EC sileo	10	564	441	114	170	202	532	397	420
RSI 80–50 EC sileo	10	683	541	133	144	882	656	497	520
RSI 100–50 EC sileo	10	683	541	133	215	982	678	498	520

Table 4

	J	K	L	M	c/c N	O	P
RSI 60–35 M1 sileo	717	597	55	598	620	640.5	708
RSI 60–35 M3 sileo	717	597	55	598	620	641	705
RSI 60–35 L1 sileo	717	597	55	598	620	641	705
RSI 60–35 L3 sileo	717	597	55	598	620	640.5	708
RSI 70–40 L1–L3 sileo	787	596	55.5	697	720	741	808
RSI 80–50 M3 sileo	882	716	55.5	797	820	841	908
RSI 80–50 L3 sileo	882	717	55.5	797	820	841	908

Table 4 (continued)

	J	K	L	M	c/c N	O	P
RSI 100–50 L3	982	746	55.5	998	1020	1041	1108
RSI 60–35 EC sileo	717	597	55	598	620	641	705
RSI 70–40 EC sileo	787	598	55.5	697	720	741	808
RSI 80–50 EC sileo	882	716	55.5	797	820	841	908
RSI 100–50 EC sileo	982	746	55.5	998	1020	1041	1108

12.3 Wiring diagrams

Abbreviation in wiring diagram	Cable colour
RD	Red
YE	Yellow
BU	Blue
WH	White
GN	Green
BN	Brown
BK	Black
GR	Grey
GY	Green/Yellow

12.3.1 Wiring diagrams for AC fans

KE fans	RS fans	RSI fans	1-phase 230 V
KE 50–25–4**	RS 60–35 L1	RSI 60–35 L1	
KE 50–30–6**	RS 60–35 M1	RSI 60–35 M1	
KE 60–30–6**	RS 70–40 L1	RSI 70–40 L1	

RS fans	1-phase 230 V
RS 30–15	
RS 40–20 L	
RS 40–20 M	
RS 50–25	

KT fans	RS fans	RSI fans	3-phase 230 V
KT 50-25-4	RS 60-35 L3	RSI 60-35 L3	
KT 50-25-6	RS 60-35 M3	RSI 60-35 M3	
KT 50-30-4**	RS 70-40 L3	RSI 70-40 L3	
KT 60-30-4	RS 80-50 L3	RSI 80-50 L3	
KT 60-30-6	RS 60-35 M3	RSI 60-35 M3	
KT 60-35-4	RS 100-50 L3	RSI 100-50 L3	
KT 60-35-6			
KT 70-40-4			
KT 70-40-6			
KT 80-50-6			
KT 100-50-6**			

KT fans	RS fans	RSI fans	3-phase 400 V
KT 50-25-4	RS 60-35 L3	RSI 60-35 L3	
KT 50-25-6	RS 60-35 M3	RSI 60-35 M3	
KT 50-30-4**	RS 70-40 L3	RSI 70-40 L3	
KT 60-30-4	RS 80-50 L3	RSI 80-50 L3	
KT 60-30-6	RS 60-35 M3	RSI 60-35 M3	
KT 60-35-4	RS 100-50 L3	RSI 100-50 L3	
KT 60-35-6			
KT 70-40-4			
KT 70-40-6			
KT 80-50-6			
KT 100-50-6**			

KT fans	3-phase 400 V
KT 40-20-4	

12.3.2 Wiring diagrams for EC fans

Note:

An internal potentiometer is installed on the terminal block from the factory. Remove the internal potentiometer when you use an external speed controller for the EC fan.

RS EC	RSI EC	1-phase 230 V
RS 30–15 EC	RSI 60–35 EC	
RS 40–20 EC	RSI 70–40 EC	
RS 50–25 EC		
RS 60–35 EC		
RS 70–40 EC		

RS EC	RSI EC	3-phase 400 V
RS 80–50 EC	RSI 80–50 EC	
RS 100–50 EC	RSI 100–50 EC	

- A. 11 & 14 = Alarm
 For operation: the relay is energized, connections 11 and 14 are bridged
 For fault: the relay is de-energized (diagnostics/faults)
 Contact rating maximum AC 250 V 2 A
- B. External potentiometer
- C. External input DC 0...10 V
- D. External ON/OFF control through potential free contact

12.3.3 Wiring diagrams for speed controller for AC motors

Note:

The selection of electrical accessories must be done in line with the technical parameters of the product.

RE	
Manual 5-step transformer.	


- A. Relay connection. There is always 230 V between ~ and N when the transformer knob is in one of the positions 1–5.
- B. Mains supply
- C. Earth
- D. Fan

REE — Thyristor	
REE 1 and REE 2 - Surface mounting or with flush mounting casing included.	
REE 4 - Surface mounting.	
Note:	
Starting currents must be considered when you select the speed controller type. Products that are used with this speed controller must have a built-in overheating protection and must be designed for thyristor speed control.	


- L: the connection with cutting function on the speed control.
- (L): the connection without cutting function.

REU	
Manual 5-step transformer for high/low speed operation. Used together with a change-over contact, for example a timer or a thermostat.	

1. External change-over contact
 2. Left selector switch
 3. Right selector switch
- A. Fan
 - B. Earth
 - C. Mains supply




- A. Relay connection. There is always 230 V between ~ and N when the transformer knob is in one of the positions 1–5.
- B. Mains supply
- C. Earth
- D. Fan
- E. Thermostat
- F. Motor protection. If the motor protection is not in use, Tk must be looped together.



- A. Contact rating, maximum AC 250 V/2 A
- B. Digital In 1
- C. Analog In 1
- D. Mains supply, 1–phase 208...277 V, 50/60 Hz
- E. Motor with internal thermal contacts
- F. OFF/ON

RTRD


A 3-phase transformer that controls the fan speed by altering the supply voltage in five fixed steps. The steps are adjusted by using the control knob on the front of the unit.



- A. If the function is not necessary, the terminals must be bridged
- B. Contact rating, 230 V AC/maximum 1 A
- C. OFF/ON
- D. OFF/ON (only by reset)
- E. Mains supply, 3–phase 400 V 50/60 Hz
- F. 3–phase motor with internal thermal contacts

RTRDU

Manual 5-step transformer with motor protection — a 3-phase transformer that controls the fan speed by altering the supply voltage in five fixed steps. The steps are adjusted by using the control knob on the front of the unit.




- A. If the function is not necessary, the terminals must be bridged
- B. Contact rating, 230 V AC/maximum 1 A
- C. Time switch
- D. OFF/ON
- E. OFF/ON (only by reset)
- F. Mains supply, 3-phase 400 V 50/60 Hz
- G. 3-phase motor with internal thermal contacts


12.3.4 Wiring diagrams for speed controllers for EC motors

Note:


An internal potentiometer is installed on the terminal block from the factory. Remove the internal potentiometer when you use an external speed controller for the EC fan.




MTP 20




EC-Basic




MTV-1/10





S-5EC/FRQ





EC-Vent



12.3.5 Wiring diagrams for ON/OFF controls for EC motors




12.3.6 Wiring diagrams for demand control for EC motors




EC-Vent

Demand control for up to 5 external sensors, 2 fans, dampers, heaters and coolers.


The EC vent system has 2 units. The control board (CB) and the room unit (RU). Connect the fan to the control board and remove the internal potentiometer.



Room Unit (RU)



Control Board (CB)



- A. Mains supply, 230 V 1~AC (10 A)
- B. Analogue sensor (for example, pressure sensor)
- C. Analogue sensor (for example, pressure sensor type PT1000)
- D. Digital sensor (for example, IR presence detector)
- E. Alarm output (maximum 24 V AC/DC, maximum 500 mA $\text{Cos}\phi > 0.95$)
- F. Output to EC fan
- G. Output to analogue actuator with 24 V DC supply
- H. Output to digital signal (DC, maximum 24 V, 1 maximum 50 mA)
- I. Output to analogue actuator (for example, heat regulator)
- J. Connection to Modbus
- K. Connection to room unit (RU)

MM6-24/D output signal selector


Compares signals from connected inputs and transfers the signal to the control output.

1	Input 1	0...10 V
2	Input 2	0...10 V
3	Input 3	0...10 V
4	Input 4	0...10 V
5	Input 5	0...10 V
6	Input 6	0...10 V

7	System neutral	Mains supply
8	24 V AC	
9	Signal neutral	
10	Signal neutral	
11	Output minimum	0...10V
12	Output maximum	0...10V


PCA 1000D2 Pressure controller

For constant air volume control (CAV) or variable air volume control (VAV).



1. Mains supply 10...24 V DC
2. Output 0...10 V
3. Pressure connections
4. Voltage input for switch on Setpoint 1/Setpoint 2

13 Accessory overview



- | | |
|----------------------------------|---|
| 1. WSG: Wall grid | 7. LDR: Silencer |
| 2. FFK: Filter cassette | 8. PGK: Water cooling battery or VBR: Water heating battery |
| 3. TUNE-S: Volume control damper | 9. RB: Electrical duct heaters |
| 4. DS: Flexible connection | 10. Balance S supply air diffuser |
| 5. Fan | |
| 6. DS: Flexible connection | |

Note:

The selection of accessories shown are not supplied with the product. For more information and other available accessories, refer to www.systemair.com or speak to Systemair technical support.

14 EU Declaration of Conformity

We, the manufacturer

Manufacturer	Systemair Sverige AB
Address	Industrivägen 3 739 30 Skinnskatteberg Sweden

declare under our sole responsibility that the products

Machine	Rectangular duct fan
Type/Model	KE, KT, RS, RSI

fulfils the relevant provisions of following directives and standards

Machinery Directive 2006/42/EC

EN ISO 12100:2010

Safety of machinery – General principles for design - Risk assessment and risk reduction

EN ISO 13857:2019

Safety of machinery – Safety distances to prevent hazard zones being reached by upper or lower limbs

EN 60204-1:2018

Safety of machinery – Electrical equipment of machines – Part 1: General requirements

EN 60335-1:2012

Household and similar electrical appliances – Safety Part 1: General requirements.

EN 60 335-2-80:2003

Household and similar electrical appliances – Safety – Part 2-80: Particular requirements for fans.

EN 50106:2008

Safety of household and similar appliances – Particular rules for routine tests referring to appliances under the scope of EN 60 335-1.

EN 60529:2014

Degrees of protection provided by enclosures (IP Code).

Directive electromagnetic compatibility (EMC) 2014/30/EU

EN 62233:2008

Measurement methods for electromagnetic fields of household appliances and similar apparatus with regard to human exposure

EN 61000-6-2:2005

Electromagnetic compatibility (EMC) – Part 6-2: Generic standards – Immunity for industrial environments.

RoHS Directive 2011/65/EU and amendment (EU) 2015/863

EN IEC 63000:2018

Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

Ecodesign Directive 2009/125/EC

327/2011 Requirements for fans above 125W

1253/2014 Requirements for ventilation units above 30W

1254/2014 Requirements for energy labelling of residential ventilation units

EN ISO 5801:2017

Fans – Performance testing using standardized airways.

EN 13142:2021

Ventilation for buildings – Components/Products for residential ventilation – required and optional performance characteristics.

Persons authorized to compile the technical file:



Stefan Lindberg

Technical Manager

This declaration relates exclusively to the machinery in the state in which it was placed on the market and excludes components which are added or operations carried out subsequently by the final user.

Skinnskatteberg, Sweden 2023-08-28



Sofia Rask

Managing Director

15 UK Declaration of Conformity

We, the manufacturer

Manufacturer	Systemair Sverige AB
Address	Industrivägen 3 SE-73930 Skinskatteberg Sweden

declare under our sole responsibility that the products

Machine	Rectangular duct fan
Type/Model	KE, KT, RS, RSI

fulfils the relevant provisions of following directives and standards

Supply of Machinery (Safety) Regulations 2008

EN ISO 12100:2010

Safety of machinery – General principles for design - Risk assessment and risk reduction

EN ISO 13857:2019

Safety of machinery – Safety distances to prevent hazard zones being reached by upper or lower limbs

EN 60204-1:2018

Safety of machinery – Electrical equipment of machines – Part 1: General requirements

EN 60335-1:2012

Household and similar electrical appliances – Safety Part 1: General requirements.

EN 60 335-2-80:2003

Household and similar electrical appliances – Safety – Part 2-80: Particular requirements for fans.

EN 50106:2008

Safety of household and similar appliances – Particular rules for routine tests referring to appliances under the scope of EN 60 335-1.

EN 60529:2014

Degrees of protection provided by enclosures (IP Code).

Electromagnetic Compatibility Regulations 2016

EN 62233:2008

Measurement methods for electromagnetic fields of household appliances and similar apparatus with regard to human exposure

EN 61000-6-2:2005

Electromagnetic compatibility (EMC) – Part 6-2: Generic standards – Immunity for industrial environments.

The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

EN IEC 63000:2018

Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

The Ecodesign for Energy-Related Products and Energy Information (Amendment) (EU Exit) Regulations 2019

327/2011 Requirements for fans above 125W

1253/2014 Requirements for ventilation units above 30W

1254/2014 Requirements for energy labelling of residential ventilation units


EN ISO 5801:2017

Fans – Performance testing using standardized airways.

EN 13142:2021

Ventilation for buildings – Components/Products for residential ventilation – required and optional performance characteristics.

Persons authorized to compile the technical file:



Stefan Lindberg

Technical Manager

This declaration relates exclusively to the machinery in the state in which it was placed on the market and excludes components which are added or operations carried out subsequently by the final user.

Skinskatteberg, Sweden 2023-08-28



Sofia Rask

Managing Director



Systemair Sverige AB
Industrivägen 3
SE-739 30 Skinnskatteberg

+46 222 440 00
mailbox@systemair.com
www.systemair.com

© Copyright Systemair AB
All rights reserved
EOE

Systemair AB reserves the rights to alter their products without notice. This also applies to products already ordered, as long as it does not affect the previously agreed specifications.