

Communicative damper actuator for adjusting dampers in technical building installations

- Air damper size up to approx. 8 m²
- Torque motor 40 Nm
- Nominal voltage AC/DC 24 V
- Control modulating, communicative 2...10 V variable

Electrical

Functional

- Position feedback 2...10 V variable
- Conversion of sensor signals
- Communication via Belimo MP-Bus

Technical data



Technical data sheet

ta	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V
	Power consumption in operation	4.5 W
	Power consumption in rest position	1.6 W
	Power consumption for wire sizing	7 VA
	Connection supply / control	Cable 1 m, 4 x 0.75 mm ²
а	Torque motor	40 Nm
	Torque variable	25%, 50%, 75% reduced
	Communicative control	MP-Bus
	Operating range Y	210 V
	Input Impedance	100 kΩ
	Operating range Y variable	Start point 0.530 V End point 2.532 V
	Options positioning signal	Open/close 3-point (AC only) Modulating (DC 032 V)
	Position feedback U	210 V
	Position feedback U note	Max. 0.5 mA
	Position feedback U variable	Start point 0.58 V End point 2.510 V
	Position accuracy	±5%
	Direction of motion motor	selectable with switch 0/1
	Direction of motion note	Y = 0 V: At switch position 0 (ccw rotation) / 1 (cw rotation)
	Direction of motion variable	electronically reversible
	Manual override	with push-button, can be locked
	Angle of rotation	Max. 95°
	Angle of rotation note	can be limited on both sides with adjustable mechanical end stops
	Running time motor	150 s / 90°
	Running time motor variable	75290 s
	Adaptation setting range	manual
	Adaptation setting range variable	No action Adaptation when switched on Adaptation after pushing the gear disengagement button
	Override control	MAX (maximum position) = 100% MIN (minimum position) = 0% ZS (intermediate position, AC only) = 50%

GM24A-MP



Fun

Technical data sheet

~	v	n .	4 4		U I	
G	W		4 4 4		VI.	Ρ
U	1.1			-	VЦ	

nctional data	Override control variable	MAX = (MIN + 32%)100%
		MIN = 0%(MAX - 32%)
		ZS = MINMAX
	Sound power level, motor	45 dB(A)
	Mechanical interface	Universal shaft clamp reversible 1226.7 mm
	Position indication	Mechanically, pluggable
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Degree of protection IEC/EN	IP54
	Degree of protection NEMA/UL	NEMA 2
	Enclosure	UL Enclosure Type 2
	EMC	CE according to 2014/30/EU
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14
	Certification UL	cULus according to UL60730-1A, UL60730-2-14 and CAN/CSA E60730-1
		The UL marking on the actuator depends on the production site, the device is UL-compliant
		in any case
	Mode of operation	Туре 1
	Rated impulse voltage supply / control	0.8 kV
	Pollution degree	3
	Ambient temperature	-3050°C
	Storage temperature	-4080°C
	Ambient humidity	Max. 95% RH, non-condensing
	Servicing	maintenance-free
Weight	Weight	1.6 kg

Safety notes



- The device must not be used outside the specified field of application, especially not in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the device and that it is ensured that the ambient conditions remain within the thresholds according to the data sheet at any time.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- Cables must not be removed from the device.
- To calculate the torque required, the specifications supplied by the damper manufacturers concerning the cross-section, the design, the installation situation and the ventilation conditions must be observed.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Product features

Mode of operation Conventional operation:

The actuator is connected with a standard modulating signal of 0...10 V and drives to the position defined by the positioning signal. The measuring voltage U serves for the electrical display of the actuator position 0.5...100% and as slave control signal for other actuators. Operation on Bus:

The actuator receives its digital positioning signal from the higher level controller via the MP-Bus and drives to the position defined. Connection U serves as communication interface and does not supply an analogue measuring voltage.



Technical data sheet

Converter for sensors	Connection option for a sensor (passive or active sensor or switching contact). The MP actuator serves as an analogue/digital converter for the transmission of the sensor signal via MP-Bus to the higher level system.
Parametrisable actuators	The factory settings cover the most common applications. Single parameters can be modified with the Belimo Service Tools MFT-P or ZTH EU.
Simple direct mounting	Simple direct mounting on the damper shaft with a universal shaft clamp, supplied with an anti- rotation device to prevent the actuator from rotating.
Manual override	Manual override with push-button possible (the gear is disengaged for as long as the button is pressed or remains locked).
Adjustable angle of rotation	Adjustable angle of rotation with mechanical end stops.
High functional reliability	The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.
Home position	The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out a synchronisation. The synchronisation is in the home position (0%).
	The actuator then moves into the position defined by the positioning signal.
	$(1) \frac{Y = 0 V}{Y = 0 V} \xrightarrow{\text{ccw}} (1) \frac{Y = 0 V}{Y = 0 V} \xrightarrow{\text{ccw}} (1) \frac{Y = 0 V}{V = 0 V}$
Adaptation and synchronisation	An adaption can be triggered manually by pressing the "Adaption" button or with the PC-Tool. Both mechanical end stops are detected during the adaption (entire setting range).
	Automatic synchronisation after pressing the gearbox disengagement button is configured. The

Automatic synchronisation after pressing the gearbox disengagement button is configured. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the positioning signal.

A range of settings can be adapted using the PC-Tool (see MFT-P documentation)

Accessories

Gateways	Description	Туре
	Gateway MP zu BACnet MS/TP	UK24BAC
	Gateway MP to Modbus RTU	UK24MOD
Electrical accessories	Description	Туре
	Positioner for wall mounting	CRP24-B1
	Feedback potentiometer 10 k Ω add-on	P10000A
	Feedback potentiometer 1 k Ω add-on	P1000A
	Feedback potentiometer 140 Ω add-on	P140A
	Feedback potentiometer 200 Ω add-on	P200A
	Feedback potentiometer 2.8 kΩ add-on	P2800A
	Feedback potentiometer 5 k Ω add-on	P5000A
	Feedback potentiometer 500 Ω add-on	P500A
	Auxiliary switch 1 x SPDT add-on	S1A
	Auxiliary switch 2 x SPDT add-on	S2A
	Positioner for wall mounting	SGA24
	Positioner for built-in mounting	SGE24
	Positioner for front-panel mounting	SGF24
	Signal converter voltage/current 100 kΩ Supply AC/DC 24 V	Z-UIC
	MP-Bus power supply for MP actuators	ZN230-24MP
Mechanical accessories	Description	Туре
	Actuator arm for standard shaft clamp	AH-GMA
	Ball joint suitable for damper crank arm KH8 / KH10	KG10A
	Damper crank arm Slot width 8.2 mm, clamping range Ø1425 mm	KH10
	Anti-rotation mechanism 230 mm, Multipack 20 pcs.	Z-ARS230
	Base plate extension for GMA to GM, pcs.	Z-GMA
	Position indicator, Multipack 20 pcs.	Z-PI
	Mounting kit for linkage operation for flat installation	ZG-GMA



Technical data sheet

GM24A-MP

s C	Description	Туре
Ā	Adapter for Service-Tool ZTH	MFT-C
E	Belimo PC-Tool, Software for adjustments and diagnostics	MFT-P
	Connection cable 5 m, A: RJ11 6/4 ZTH EU, B: 6-pin for connection to service socket	ZK1-GEN
	Connection cable 5 m, A: RJ11 6/4 ZTH EU, B: free wire end for connection to MP/PP terminal	ZK2-GEN
c	Service Tool, with ZIP-USB function, for parametrisable and communicative Belimo actuators, VAV controller and HVAC performance devices	ZTH EU

Electrical installation




Supply from isolating transformer.


Service

Parallel connection of other actuators possible. Observe the performance data.

Wiring diagrams




Cable colours: 1 = black 2 = red 3 = white 5 = orange




Functions

Functions when operated on MP-Bus Connection on the MP-Bus



Connection of active sensors




(max. 8)

A) additional MP-Bus nodes

A) additional MP-Bus nodes (max. 8)

- Supply AC/DC 24 V
- Output signal DC 0...10 V (max. DC 0...32 V)
- Resolution 30 mV



MP-Bus Network topology

MP 1 L 2 3 5 U

There are no restrictions for the network topology (star, ring, tree or mixed forms are permitted). Supply and communication in one and the same 3-wire cable • no shielding or twisting necessary • no terminating resistors required


A) additional MP-Bus nodes (max. 8)

 Switching current 16 mA @ 24 ٧

• Start point of the operating range must be parametrised on the MP actuator as $\geq 0.5 \text{ V}$



Connection of passive sensors





Ni1000	–28+98°C	8501600 Ω ²⁾
PT1000	–35+155°C	8501600 Ω ²⁾
NTC	-10+160°C ¹⁾	200 Ω60 kΩ ²⁾

A) additional MP-Bus nodes (max. 8) 1) Depending on the type 2) Resolution 1 Ohm Compensation of the measured value is recommended

Functions with basic values (conventional mode)


Override control with AC 24 V with relay contacts Т







Minimum limit with positioner SG..

Control remotely 0...100% with positioner SG..






Follow-up control (position-dependent)




Functional check




Procedure


1. Connect 24 V to connections 1 and 2 2. Disconnect connection 3: - with direction of rotation 0: Actuator rotates to the left - with direction of rotation 1: Actuator rotates to the right 3. Short-circuit connections 2 and 3: - Actuator runs in opposite direction

Override control with AC 24 V with rotary switch





Control with 4...20 mA via external resistor



Caution:


The operating range must be set to DC 2...10 V. The 500 Ω resistor converts the 4...20 mA current signal to a voltage signal DC 2...10 V




Technical data sheet


Functions for actuators with specific parameters (Parametrisation necessary)

Override control and limiting with AC 24 V with relay contacts



1) Caution: This function is only guaranteed if the start point of the operating range is defined as min. 0.5 V.





0	Direction of rotation switch		
	Switch over:	Direction of rotation changes	
2	Push-button and	LED display green	
	Off: On: Press button:	No power supply or malfuntion In operation Triggers angle of rotation adaptation, followed by standard mode	
3	Push-button and	LED display yellow	
	Off: Flickering: On: Flashing: Press button:	Standard mode MP communication active Adaptation or synchronising process active Request for addressing from MP master Confirmation of the addressing	
4	Gear disengagen	nent button	
	Press button: Release button:	Gear disengages, motor stops, manual override possible Gear engages, synchronisation starts, followed by standard mode	
5	Service plug For connecting pa	rameterisation and service tools	
Ch	eck power supply	connection	
		Possible wiring error in power supply	

10 V

(DC 0...1



Service


Service Tools connection

The actuator can be parametrised by ZTH EU via the service socket. For an extended parametrisation the PC tool can be connected.

Connection ZTH EU / PC-Tool



Dimensions



Clamping range

	OI	
	1222	1218
× P	01	₽₽
	2226.7	1218

Shaft length



Min. 52



Min. 20

Further documentation

- Overview MP Cooperation Partners
- Tool connections
- Introduction to MP-Bus Technology